



Nose Box Starter/Generator Controller and related logic

Raise the Master Relay as a Precondition

Call lines to engine mounted Stand Gen Controller

REV	1	23/06/2018	Initial Issue
REV	2	23/06/2018	Final Issue
REV	3	23/06/2018	Final Issue