


Consider running bendix solenoid to the energize side of starter solenoid.



Upper wall of fuselage to the right of the tank near the firewall